X4-LIFE

GB

Security TV simulator

USER MANUAL

Art.-Nr. 701377

CE

Contents

1. ___ Information on this user manual. ... 12
2. ___ Checking the contents ... 12
3. ___ Contents ... 12
4. ___ Designated use. ... 12
5. ___ General notes ... 13
6. ___ Importer and service ... 14
7. ___ Safety guide ... 14
8. ___ Cable and plug ... 16
8.1 __ Connection and Start-Up ... 17
9. ___ Cleaning and maintenance ... 18
10. __ Disposal ... 18
11. __ Specifications ... 19

Security TV simulator

We are pleased that you have decided to buy our product. We wish you were a lot of fun with this product.

1. Information on this user manual

This user manual contains important information for the safe use of the product.
Therefore, for your own safety and for a successful use, please read this user manual completely before assembling and using the product.

2. Checking the contents

When unpacking your package make sure that all components are there and intact. If any components are missing or damaged please contact a specialist or your local dealer immediately.

Keep the packing and user manual in a safe place for future transport. When passing on the product to another person, be sure to include the user manual.

3. Contents

Security TV simulator | Power supply | User manual

4. Designated use

This light effect may only be used inside rooms and buildings. The designated use is defined by the instruction manual and in following the appliance and the warnings mentioned in this user manual. This device is not designed for industrial use.

This product serves to prevent burglars from breaking into your house by simulating the presence of people at home.

The light of integrated colored LEDs changes randomly between colors, brightness and in this way simulates scene and color changes from a normal TV-program.
With the help of a brightness sensor you can choose the device to automatically activate for 4 to 8 hours by nightfall.

This product is not suitable for household illumination.
The LED lamps cannot be changed in the luminaire.

5. General notes

All mentioned company and product names are registered trademarks under the rights of their owners.
© All rights reserved.

No liabilities will be taken for damages or claims resulting out of not reading and/or not following the user guide and/or any form of modification on or in the product. Under these circumstances, no warranty services will be given.
Liability cannot be taken for consequential damages.

The contents of this user manual may differ from the product. If so, please consult additional manuals in the packing. Keep this user manual in a safe place. If you give this product away to a third party, make sure that you also pass on the user manual.

The CE conformity has been declared and proven, and the corresponding documents have been deposited with the manufacturer. For the reason of safety and CE-licensing it is not allowed to modify this unit in any way and/or use it for functions, other than the designated use.

6. Importer and service

Service Address	**lived non food GmbH** TOR 8 – 9 Donaustraße 20 D-38120 Braunschweig
Fon	+49 (0) 531/224356-82
E-Mail	service@x4-life.de
Internet	www.x4-life.de

Address	**lived non food GmbH** Donaustraße 20 D-38120 Braunschweig
E-Mail	info@lived-non-food.de
Internet	www.lived-non-food.de

7. Safety guide

- Please read the safety guide before using the product. This information is for your safety and the protection of the device and devices connected. You will also find specific safety instructions in the following chapters of this user manual.

- This product is not a toy and should not be handled by infants and small children. Children cannot assess the dangers connected with electrical devices.

- Do not leave the packaging material lying around. Children might play with the plastic bags and risk suffocation.

- This device should only be opened and/or repaired by an expert or a person who is qualified to do so. Only original spare parts may be used.

- Keep this product away from water, dampness and high humidity. Keep this product away from vessels containing liquids, e.g., buckets, vases or plants.

- Make sure that this device is mounted in a place with sufficient ventilation

- Make sure that the connector cables to not become a hazard. The mains cable should not be bent, squashed or damaged by sharp edges.

- Should the mains cable show any signs of damage, do not use the device. Detach it from the mains plug immediately and let it be repaired by a qualified person.

- All persons installing, handling or using this device should be qualified to do so and follow the instruction manual.

- The product may not be subjected to extreme heat or cold. Do not expose the product to intense sunlight, open fire or other heat sources: Storage temperature: -0°C to 60°C; Working temperature: 0°C to 40°C

- Do not use this device in a tropical humid climate. If the product is brought in from the cold to a warm area (e.g., during transport), condensation can occur within the unit. Let the device reach room temperature, before you use it.

- Considering the large number of different types of varnishes and polishes used for furniture, it is possible that the device's feet will leave visible residue on the furniture as a result of a chemical reaction. The product should therefore not be placed on the surfaces of furniture without suitable protection.

- This device may only be used indoors. Make sure that it is not subjected to water or high humidity.

CAUTION! Very bright LED light.Never watch directly into the LED light beam nor use optical devices to look at it.

- People suffering from photo-sensitive epilepsy, are susceptible to epileptic seizures or loss of consciousness if exposed to flashing lights or light patterns. If symptoms such as dizziness, blurred vision, eye or muscle twitching, loss of awareness, disorientation, any involuntary movement or convulsion should occur, the light effect should be switched off or the person should leave the room.

- If you have doubts on the function or questions, please contact your local dealer or our service center.

8. Cable and plug

WARNING! There is a risk of injury if the cable and plug are damaged! The RGB LED Strip is powered by electric current.

Therefore please pay special attention to the following when using the cable and plug:

- Never touch the plug with wet hands.
- If you want to take the plug out of the socket, always pull it directly at the plug. Never pull it out by the cable, as this could break.
- Cables must never be crushed, folded over, damaged by sharp edges or subjected to any other kind of mechanical stress.
- Avoid exposing cables to excessive heat or cold.

- If the mains cable or another cable connected to the RGB LED Strip is damaged, it must be replaced by the manufacturer or a similarly qualified person (e.g. a qualified electrician).
- For safety reasons always take the plug out of the socket in the event of a thunderstorm.
- Take the plug out of the socket during installation and cleaning, and when the product is not in use.

8.1 Connection and Start-Up

The plug in is used as a disconnecting device and always has to be ready for operation.

Connect the plug in with the provided socket on the TV-Simulator. Afterwards plug it into a mains socket at home. You can now choose between following functions by using the slide switch on the upper side of the device:

- "OFF" The device is permanently turned off.
- "ON" The device is permanently turned on. This function is recommended if you want to use a clock timer for manually regulated operation. This way, the device can also be used at daytime or by chance.
- "Dämmerung +4 Stunden" The control lamp shines blue. The device turns itself on at dusk and simulates a TV-Programm for 4 hours. As soon as the environment brightness falls under the threshold of the sensor the next day, the device will turn on again repeatedly
- "Dämmerung +8 Stunden" The control lamp shines red. The function is the same as mentioned in "Dämmerung +4 Stunden" but the device will turn itself on for 8 hours.

☛ *Be aware that you place the device on a stable surface so it cannot drop on the floor.*

You should place the device in an area that is not observably from outside, so burglars may not notice if it's a real TV.
Check the impression of the Simulator from outside your house and maybe replace the device, to make sure you have a good impression of a TV.

Never cover the TV-Simulator norfocus it with a lamp or Spotlight. Otherwise the Simulator could possibly turn itself on unwanted, due to the brightness sensor (Only in "Dämmerung +4 Stunden" or "Dämmerung +8 Stunden" settings).

9. Cleaning and maintenance

Always use a soft, dry and lint-free cloth to clean the unit's exterior. If the device is extremely dirty you can use a soft cloth, dampened with water or a mild cleaning solution to clean. Never use any abrasive or harsh cleaning agents (e.g. alcohol, petrol or thinners) as these could damage the controls, casing or any markings and labels found on the device.

10. Disposal

Electrical- and electronic devices must never be disposed of in the regular household waste!

Consumers are legally obligated and responsible for the proper disposal of electronic and electrical devices by returning them to collecting sites designated for the recycling of electrical and electronic equipment waste. For more information concerning disposal sites, please contact your local authority or waste management company.

11. Specifications

- Power consumption < 3 watt
- Light sensor and timer
- 20 extra bright LEDs
- Dimensions (W x H x D): 80 x 70 x 60 mm
- Input voltage: 100 – 240 V AC
- Frequency: 50/60 Hz
- Output voltage: 5 V DC
- Operating Voltage: 5 V

Guarantee and service conditions
You receive a voluntary 2-year manufacturer guarantee, starting at purchase date, for material and production defects of the product. This guarantee is applicable in Germany, Austria and Switzerland. The receipt counts as a proof of guarantee. Within the guarantee period we will repair all material and manufacturer defects free of charge. Your statutory warranties remains unaffected by this guarantee.

The guarantee does not count:
- in case of damages which have arisen after improper use
- for wear parts / accessories that are subject to natural wear and tear
- for defects that are known to the customer at purchase
- in case of damages that occurred due to repair or intervention of the buyer or an unauthorized third party
- in case the device was connected to a higher voltage as stated on the device
- when dropping the device or single elements of it
- for improper transportation or packaging
- damages that occurred due to force majeure
- for non-observance of valid safety precautions
- for non-observance of the manual

Batteries / rechargeable batteries are not covered by the guarantee as they are parts of consumption.
In case of a guarantee claim, the date of sale has to be proven by receipt or invoice. Replacements for reasons covered by the guarantee do not lead to an extension of the original guarantee period, neither for the device itself nor for any replaced components. If you are claiming a valid guarantee, we are entitled to choose whether we will repair the device free of charge or exchange it for a new device. Any further claims are excluded. Parts replaced will pass into our property. We reserve the right to change defective parts or products against follow-up models.

Please always contact us before you return your product.

Provided that a return shipment has been agreed, send the defective product securely packaged at your own cost to our service department:

lived non food GmbH
Tor 8 – 9
Donaustraße 20
38120 Braunschweig
E-Mail: service@lived-non-food.de
Tel: +49 (0) 531 224 356 82

It is absolutely necessary that you add a copy of your receipt to your return shipment. Repairs carried out after the guarantee period are subject to a charge. We will not accept freight collect shipments and will return them to the sender.

lived non food GmbH,
all rights reserved.

No liability will be taken for modifications or mistakes regarding the technical data or product features described in this user manual.

All rights reserved. Any reproduction, transfer, duplication or filing of this user manual or parts of it, as well as the translation into a foreign language or computer language is prohibited without the explicit approval of the manufacturer. Due to the fast advancement of these products, no guarantee of completeness can be given. Modifications in technique and configuration are subject to change at any time.

To receive a digital copy of this user manual, please contact our service department

X4-LIFE

8.2014